

糞便採檢棒使用說明

Instructions for using a fecal collection swab

- 步驟 1. 糞便解在乾淨塑膠袋或乾淨白紙上（不可使用坐式馬桶，否則糞便將受到馬桶水的污染）
Place the feces on a clean plastic bag or clean white paper (do not use a sitting toilet, as the feces may be contaminated by toilet water).
- 步驟 2. 採檢棒外套打開，用手拿取棉枝的塑膠頭，取出棉棒（注意手勿接觸棉棒的棉花及其他部位）。
Open the outer cover of the collection swab and take the plastic head of the cotton swab (be careful not to touch the cotton or other parts of the swab).
- 步驟 3. 以棉頭均勻沾取糞便，直至棉頭處都沾裹到糞便
Dip the cotton part into the feces until the cotton is completely covered in feces.
- 步驟 4. 打開採檢管，將棉頭放入採檢管深處並浸入液體。
Open the transport tube, put the cotton swab into the deep and soak in the buffer.
- 步驟 5. 將採檢棒從折斷點折入採檢管內，管蓋旋緊（不可將管內的液體倒出）。
Fold the cotton swab from the breaking point into the transport tube and tighten the lid (do not pour out the buffer in the tube).
- 步驟 6. 採檢管外寫上姓名，以免和別人的檢體混淆。
Write your name on the outside of the transport tube.
- 步驟 7. 採檢完室溫 1 小時內送檢，若無法立即送檢，可冷藏 2-8°C 保存 24 小時內送檢。
After specimen collection, deliver to the laboratory within 1 hour at room temperature. If immediate delivery is not possible, store at 2-8°C and submit for testing within 24 hours.

